

(1)

**AUTOGENEOUS FRICTION STIR WELD LACK-OF-PENETRATION DEFECT
DETECTION AND SIZING USING DIRECTIONAL CONDUCTIVITY
MEASUREMENTS WITH MWM EDDY CURRENT SENSOR**

Neil Goldfine, Vladimir Zilberstei, and Ablode Lawson
JENTEK Sensors, Inc.
200 Dexter Avenue
Watertown, MA 02472

David Kinchen, William Arbegast
Lockheed Martin Michoud Space Systems,
New Orleans, LA

Al 2195-T8 plate specimens containing Friction Stir Welds (FSW), provided by Lockheed Martin, were inspected using directional conductivity measurements with the MWM sensor. Sensitivity to lack-of-penetration (LOP) defect size has been demonstrated. The feature used to determine defect size was the normalized longitudinal component of the MWM conductivity measurements. This directional conductivity component was insensitive to the presence of a discrete crack. This permitted correlation of MWM conductivity measurements with the LOP defect size as changes in conductivity were apparently associated with metallurgical features within the first 0.020 in. of the LOP defect zone. Transverse directional conductivity measurements also provided an indication of the presence of discrete cracks. Continued efforts are focussed on inspection of a larger set of welded panels and further refinement of LOP characterization tools.

**Lockheed Martin Confidential
Commercial or Financial Sensitive Data**

Autogeneous Friction Stir Weld LOP Defect Detection and Sizing Using Directional Conductivity Measurements with MWM™ Eddy-Current Sensor

AeroMat Conference

June 2000

Neil Goldfine
Vladimir Zilberstein
Andrew Washabaugh

JENTEK Sensors, Inc.
Watertown, MA

William Arbegast
David Kinchen

Lockheed Martin Space Systems Company
Michoud Operations
New Orleans, LA

JENTEK™
Sensors

Lockheed Martin Confidential
Commercial or Financial Sensitive Data

Objective

- Demonstrate preliminary capability of the JENTEK MWM™ Sensor with Grid Methods to provide a measure of the lack of penetration (LOP) defect thickness for Friction Stir Welds

Specimens


Four panels with similar FSW geometry representing a range of LOP defect thickness:

- No LOP defect
- 0.02 inch thick LOP defect
- 0.04 inch thick LOP defect
- 0.09 inch thick LOP defect

MWM™ Measurements

- Single Frequency (250 kHz)
- Two-Dimensional images
- One-Dimensional “Line” scans
- Parallel and perpendicular orientation of MWM windings

Meandering Winding Magnetometer




- Thin
- Conformable
- Surface Mountable
- Configurable into an array for imaging



Transfer Impedance = Secondary Voltage / Primary (input) Current

MWM™ Probe and Replaceable MWM™-Array Sensor Tips

Calibration
Shunt Tip



Sensor Tip




Single Sensing
Element
MWM Sensor

Representative Measurement Grids


These grids relate the magnitude and phase of the transimpedance to the liftoff, and

(a) conductivity for aluminum, and

(b) magnetic permeability for low alloy steel




(a) Aluminum




(b) Low-Alloy Steel


MWM™ and MWM-Array Probes



Single Element Conformable MWM Probe for Flat and Curved Surfaces




MWM-Arrays for Continuous
On-Line Fatigue Test Monitoring
and In-Service Monitoring



MWM-Array for On-Line Contact or
Non-Contact C-Scan Imaging


New Portable JENTEK Mini-GridStation™




JENTEK™
Sensors

Lockheed Martin Confidential
Commercial or Financial Sensitive Data

MWM-Array On-Line



MWM-Array
mounted in .25 inch hole




Remote Instrument Module (RIM)
with on-line coupon fixture/cables

Future Efforts

- Customization of an MWM-Array for scanning of FSW welds with an increased spatial wavelength to provide increased depth of penetration and high spatial image resolution for LOP detect mapping and crack detection
- Investigation of multiple frequency methods with a deeper penetration probe for differentiating small LOP defects below 0.03 inches (future effort)
- Investigation of the relationship between MWM responses and FSW microstructure variations
- Investigation of high temperature in-process MWM-Array monitoring of microstructure variations


MWM Probe and Scan Orientations Relative to Weld Axis

MWM with Perpendicular
Orientation Relative to Weld Axis



MWM Probe and Scan Orientations Relative to Weld Axis


MWM with Parallel Orientation
Relative to Weld Axis



MWM Sensor Response



(Minimum Center Region Normalized Conductivity) as a Function of Lack of Penetration Defect Thickness

Minimum Center Region Normalized Conductivity





Normalized MWM Conductivity Scans for Friction Stir Weld Specimens

Conductivity Scans with MWM Oriented Parallel to Weld




Normalized MWM Conductivity Scans for Friction Stir Weld Specimens

Conductivity Scans with MWM Oriented Perpendicular to Weld



Normalized MWM Conductivity Scans for Friction Stir Weld Specimens


Conductivity Scans with MWM Oriented Perpendicular to Weld




- Δ - LM60-07-I2, 21" mark Perp., LOP=0.04
- ○ - LM60-07-N1, 3" mark Perp., LOP=0.09
- ◇ - LM60-07-N1, 6" mark Perp., LOP=0.09
- □ - LM60-07-N1, 9" mark Perp., LOP=0.09

Only the locations with MWM Crack Indications, Determined by Perpendicular Scan Response Shape (e.g. three adjacent substantially reduced conductivity values, within 0.5% of each other) are shown in this figure.


Normalized 2-Dimensional MWM Image of Specimen LM60-07-A2, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis



Normalized 2-Dimensional MWM Image of Specimen LM60-07-A2, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis




Normalized 2-Dimensional MWM Image of Specimen LM60-07-D1, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis




Normalized 2-Dimensional MWM Image of Specimen LM60-07-D1, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis


LM60-07-D1 Parallel LOP DEPTH = 0.02




Normalized 2-Dimensional MWM Image of Specimen LM60-07-D1, at 250kHz, with MWM Longer Winding Segments Perpendicular to Weld Axis



Normalized 2-Dimensional MWM Image of Specimen LM60-07-D1, at 250kHz, with MWM Longer Winding Segments Perpendicular to Weld Axis




Normalized 2-Dimensional MWM Image of Specimen LM60-07-I2, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis




Normalized 2-Dimensional MWM Image of Specimen LM60-07-I2, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis

LM60-07-I2 Parallel LOP DEPTH = 0.04




Normalized 2-Dimensional MWM Image of Specimen LM60-07-I2, at 250kHz, with MWM Longer Winding Segments Perpendicular to Weld Axis

LM60-07-I2 Perpend. LOP DEPTH = 0.04




Normalized 2-Dimensional MWM Image of Specimen LM60-07-I2, at 250kHz, with MWM Longer Winding Segments Perpendicular to Weld Axis

LM60-07-I2 Perpend. LOP DEPTH = 0.04




Normalized 2-Dimensional MWM Image of Specimen LM60-07-N1, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis




Normalized 2-Dimensional MWM Image of Specimen LM60-07-N1, at 250kHz, with MWM Longer Winding Segments Parallel to Weld Axis

LM60-07-N1 Paralle LOP DEPTH = 0.09




Normalized 2-Dimensional MWM Image of Specimen LM60-07-N1, at 250kHz, with MWM Longer Winding Segments Perpendicular to Weld Axis

LM60-07-N1 Perpend. LOP DEPTH = 0.09



Normalized 2-Dimensional MWM Image of Specimen LM60-07-N1, at 250kHz, with MWM Longer Winding Segments Perpendicular to Weld Axis

LM60-07-N1 Perpend. LOP DEPTH = 0.09



Conclusions

- JENTEK has demonstrated capability to discriminate between LOP defect thickness of 0.02, 0.04 and 0.09 in.
- Sensitivity to LOP defect thickness is due to a correlation with microstructural changes that affect the near surface electrical conductivity within the first 0.01 inches
- JENTEK has demonstrated capability to detect cracks within AFSW